

Solid Surface Counter Tops Maintenance

Polish/smooth out Nevin Solid Surface tops



1

If surface is dull and lifeless — attach newspaper to a vibrating (*or orbital*) sander and polish the top. This will create a nice gloss finish.

2

If surface has light scratches, purchase a red Scotch-Brite™ pad (*used for cleaning dishes*) and sandwich between the counter and a vibrating or orbital sander and sand the top.



Scotch-Brite™ pads are commonly be found at your local hardware store.

3

If the scratches are deeper, and the Scotch-Brite™ pad doesn't remove the scratches, use an orbital sander with 220 grit sandpaper on the top. Wet the surface before starting to keep dust down. If scratches still show, use a heavier 400 grit sandpaper. Always make provisions to control dust.